


62" GUIDE TRACK REPLACEMENT STRIPS

ANTI-CHIP STRIP + ANTI-SLIP STRIPS KIT

Item# ACS715 Article ACS715 Artículo # ACS715 **GLIDE STRIPS**

Anti-Chip Strip

Item# ACS725 Article ACS725 Artículo # ACS725



Anti-Slip Strips

(1) Remove the cord manager and the old strips to be replaced from the guide track. Remove strip adhesive residue from the track with a label-adhesive remover (available at home centers and hardware stores). Wipe the strip locations with a clean cloth.

(2) Apply new anti-chip and anti-slip strips to the bottom of the track.

ATTENTION: The anti-chip strip must be trimmed before use. Refer to your original Kreg Adaptive Cutting System owner's manual.

(3) Apply new glide strips to the top of the track.

ATTENTION: There are a total of 5 strips.